

Stage Lighting

Quick User Guide

This small controller enables a few lights to be quickly and easily powered to provide general lighting stage for rehearsals and presentations, etc. The 24-channel dimmer control board is available for more complex applications, such as Drama productions, and this system has a separate User Guide.

To Switch On

1. Set all the **dimmer slider controls to ZERO**



Dimmer controller

2. **Switch on the controller mains power** for the controller at the mains socket below



Controller mains power
(LH socket)

3. Confirm that the **green Power light** is lit on the dimmer controller. *(If the green light is not lit, check that the small Power switch on the top of the controller is ON).*

4. **Switch on the Main Power** supply. (This is located down below the stage, in cupboard with black door).



Stage Lighting POWER SWITCH

IMPORTANT: This switch should only be operated when the lights are dimmed to **OFF**. It is an isolator switch, and is not designed to break heavy current.

5. Ensure that you leave the power cupboard door shut. (It is a Fire Door).
6. The system should now be operational.

To Switch OFF

1. Set all the **dimmer slider controls to ZERO**
2. **Switch OFF the Main Power** supply at the Main Isolator. (Located below the stage).
3. Ensure that you leave the power cupboard door shut. (It is a Fire Door).
4. **Switch off the controller mains power** (on stage) at the mains socket below. *Confirm that the **green Power light** is OFF*

- END -