

Hornby Institute
Sound System
Bass Loudspeaker

To Unplug the loudspeaker

1. Ensure the amplifiers are SWITCHED OFF in the sound cupboard*.
2. To Unplug the speaker cable (*refer to picture*):
 - a. **Pull back the metal slide catch**
and then...
 - b. **Twist** the plug anti-clockwise
and then....
 - c. **Pull** the plug from the socket.
3. Refitting is the reverse procedure

To Plug-in the loudspeaker

1. Ensure the amplifiers are SWITCHED OFF in the sound cupboard*
2. To plug-in the speaker cable to the wall socket:
 - a. **Pull back the metal slide catch**
and then...
 - b. **Twist & push** the plug until it can be inserted
and then....
 - c. **Release the Pull metal slide catch**
3. Gentle pull the plug to check correct engagement Task complete



* The sound cupboard
combination lock
number is **6934**